Blucain by BLUΞNIX

WATER FILTER



ISF

DH-R1 Filter Cartridge DH-S1 Single Filteration System

DH-S2 Dual Filtration System

Keeps ice machine functioning at full capacity.



Best Quality Ice

Eliminates off tastes and odor of ice and reduces up to 97% of disinfectant Chlorine from incoming water supply.



Cost Effective

Saves ice machine maintenance costs by reducing lime scale build up



Flawless Filtration System

Produces crystal clear ice by filtering out 96.3% of dirt and metallic particles greater han or equal to 0.5 microns.

Recommendations

Model	Description	Ice machine capacity	Compatible Blueair Models
DH-S1	2 Gpm	Up to 500 lbs	BLUI-150A BLUI-250A BLMI-300A BLMI-500A BLMI-500AD
DH-S2	2*2 Gpm	650 through 1,400 lbs	BLMI-650A BLMI-900A BLMI-1400R

Specifications

- Flow rate: 2 Gpm (7.5 Lpm)
- Pressure: 30~100 psi (2.1~7Kg f/cm²)
- Temperature: 35~100°F (2~38°C)
- Capacity: 21,000 gal. (79,494L)
- Inlet & outlet size: 3/8 inch
- Time required to flush: 5 min. or until water runs clear
- Weight of the unit when operating (filled with water)

Single system: DH-S1, 6 lbs (2.72Kg)

Dual system: DH-S2, 14 lbs (6.35Kg)

Height including filter catridge
 Single system: DH-S1, 19"

Dual system: DH-S2, 19 1/8"

Parts	5	DH-S1 Single	DH-S2 _{Dual}
Filter Head (S)		1	-
Filter Head (D)	Contraction Design State	-	1
Filter Cartridge (DH-R1)		1	2
Pressure Gauge		1	Built In(1)
Shut-off Valve		2	2
T-fitting		1	1
3/8" Tubing	Ó	12 ft	12 ft
Anchor		2	2
Screw	() 	2	2
Instructions	This guide	1	1

Connection Guide

•Step 1

Make 4 (four) 2-inch-long connection tubes by cutting provided 3/8" x 12ft Tubing as shown in Fig 1.



• Step 2.

Connect the tubes to the shut off valve and T-fitting as shown in Fig 2 & Fig 3.





*Note : Single system (DH-S1) does not need "a1" tube.

• Step 3.

Assemble all the parts of the system you have as shown in Fig 4 and 5.




Make sure that the tubes are fully inserted into the guick coupler, otherwise water may leak. Insert tube until it stops, then pull back on tube to ensure it locks in place.



System tested and certified by NSF international against NSF/ANSI Standard 42 for drinking water treatment units. Units are certified and will reduce Chlorine, class I Nominal Particulates, bad taste and odor in ice.



This product may exprose you to chemicals including Diisononyl Phthalate(DINP), which is known to the State of California to cause cancer. For more information go to www.P65War nings.ca.gov.
Ce produit peut vous exposer à des agents chimiques incluant le Diisononyl Phthalate(DINP), reconnu par l'Esat de Californie comme causant le cancer, Pour de plus amples renseignements, consulter le site www.P65Warnings.ca.gov.





D

DH-S1 DH-S2 1 9/16 9 1/16

230

40

inch D

Fig 5 (DH-S2)

V1

V2

Step 4.

Determine where you will attach the Filter Head.

Step 5.


Refer to the distance diagram and table below to determine spacing required for hanging Filter-Head and attach the Anchors to the wall.

Step 6.

Insert the Screws as shown.

•Step 7.

Hang the Filter Head on the Screws.





 Step 9 : Close the main valve of the water supply line before this step. Insert water supply tube and water outlet tube to Filter Head. Connect the other end of the water outlet tube to the machine Do not open the Shut-off Valve (V1, V2) until all Tubing is connected.



Step 10 : Check all of the tube connections and fasten them securely.

- Open the main valve of the water supply line. Open V1 valve. - Before using the machine, open the V2 valve to flush out the initial
 - filtrate. (at least 5 gallons or until clean water comes out) * You will need a container to flush out the initial filtrate water.
 - * Valve V2 must be closed after flushing.



orders@blueairfse.com

Incorrect flushing of the filtration system can cause defects in the ice maker.



Blue Air has right to change specifications without further notice.





blueairfse.com

223 W. Rosecrans Ave., CA 90248 T: 310-808-0102

9 W. Shelton Terrace #A, Hillside, NJ 07205 T: 908-688-0970